




|                                 |                                 |                                   |                                 |
|---------------------------------|---------------------------------|-----------------------------------|---------------------------------|
| <b>CZ</b> Montážní návod        | <b>RU</b> Инструкция по монтажу | <b>RO</b> Instrucțiuni de montaj  | <b>NL</b> Montage instructie    |
| <b>SK</b> Montážny návod        | <b>D/A</b> Montageanleitung     | <b>ES</b> Manual de instrucciones | <b>LT</b> Montavimo instrukcija |
| <b>GB</b> Mounting instructions | <b>PL</b> Instrukcja montażu    | <b>FR</b> Notice de montage       |                                 |

|                                |                                 |  |                                 |
|--------------------------------|---------------------------------|--|---------------------------------|
| <b>CZ</b> Specifikace dodávky  | <b>RU</b> Спецификация поставки | <b>RO</b> Componente livrate           | <b>NL</b> Leveringsomvang       |
| <b>SK</b> Špecifikácia dodávky | <b>D/A</b> Lieferumfang         | <b>ES</b> Especificación de suministro | <b>LT</b> Tiekimo specifikacija |
| <b>GB</b> Supplied equipment   | <b>PL</b> Specyfikacja dostawy  | <b>FR</b> Equipements fournis          |                                 |

SLZN 67 - Obj. č. (Code Nr.) - 95670



|                        |                                     |                        |  |
|------------------------|-------------------------------------|------------------------|--|
| <b>CZ</b> Instalace    | <b>RU</b> Схема включения и монтажа | <b>RO</b> Instalare    | <b>NL</b> Installatie                  |
| <b>SK</b> Inštalácia   | <b>D/A</b> Installation             | <b>ES</b> Instalación  | <b>LT</b> Montavimo ir įjungimo schema |
| <b>GB</b> Installation | <b>PL</b> Instalacja                | <b>FR</b> Installation |  |

| montáž s lepidlem<br>mounting with 3M VHB tape | montáž se šrouby<br>mounting with screws |  |
|--|--|--|
| <p>1</p> <p>ISOPROPYL ALCOHOL</p>              | <p>1</p>                                 |  |
| <p>2</p> <p>2 min.</p> <p>15 s.</p>            | <p>2</p>                                 |  |
| <p>3</p>                                       | <p>3</p>                                 |  |
| <p>4</p>                                       | <p>4</p>                                 |  |
| <p>5</p> <p>- 48h -</p>                        | <p>5</p>                                 |  |